USER MANUAL

Ctek Z Series Cellular Routers

Models Z4200 and Z4400

Ctek – Things That Move Data

Table of Contents

TABLE OF CONTENTS I

TABLE OF FIGURES II

PREFACE 1

1 INTRODUCTION 1

1.1 Theory Of Operation 1

1.2 Features 1

2 CONNECTORS, LIGHTS, SWITCHES, AND JUMPERS 3

2.1 Switches 3

2.2 Lights 3

2.3 Connectors (see figures 3 and 4 below) 4

3 START UP 6

3.1 Power 6

3.2 Connecting the Antenna 6

3.3 Connecting to the Ethernet Port – Administrative Connection 6

4 ADMINISTRATION, CONFIGURATION AND STATUS 7

4.1 Getting Started 7

4.2 Interfaces 11
4.2.1 Configuring The Wireless Interface 11
4.2.2 Configuring The Ethernet Interace 15
4.2.1 The RS232/RS485 Interface 17
4.2.2 Configuring The Relay Input Interface 18
4.2.3 Configuring The Relay Output (Driver) Interface 19

4.3 Status 20
4.3.1 Wireless Status 20
4.3.2 Ethernet Status 26

4.4 Services 27
4.4.1 Password Administration 27
4.4.2 Routing and Forwarding Services 27

4.4.3 Tunneling Services 30
4.4.4 Serial Communications Services 32
4.4.5 Admin Screen Services 40
4.4.6 Wireless Activation Services (Z4200 CDMA Only) 41

4.5 Options 46
4.5.1 Applications 46
4.5.2 Tools 46
4.5.3 SIM Editor (Z4400 HSPA Only) 46
4.5.4 AT Commands (Z4400 HSPA Only) 48

5 SPECIFICATIONS 49

6 CERTIFICATIONS 49

7 APPENDIX A – DISCRETE I/O ELECTRICAL DRAWINGS 50

Table of Figures

FIGURE 1 - LIGHTS AND SWITCHES 3
FIGURE 2 - DB9 CONNECTOR 4
FIGURE 3 – Z4200S MODEL CONNECTORS 5
FIGURE 4 – Z4200U MODEL CONNECTORS 5
FIGURE 5 - WINDOWS CONFIGURATION 7
FIGURE 6 - LOGIN SCREEN 8
FIGURE 7 - Z4200 TOP MENU 9
FIGURE 8 - Z4400 TOP MENU 10
FIGURE 9 - Z4200 (CDMA) WIRELESS INTERFACE 11
FIGURE 10 - Z4200 NETWORK SELECT 12
FIGURE 11 - Z4400 (HSPA) WIRELESS INTERFACE 13
FIGURE 12 - ETHERNET CONFIGURATION 15
FIGURE 13 - RS232/485 CONFIGURATION 17
FIGURE 14 - RELAY INPUT CONFIGURATION 18
FIGURE 15 - RELAY OUTPUT CONFIGURATION 20
FIGURE 16 - WIRELESS STATUS (Z4200) 21
FIGURE 17 - WIRELESS STATUS DETAILS Z4200 23
FIGURE 18 - WIRELESS STATUS Z4400 25
FIGURE 19 - ETHERNET STATUS 26
FIGURE 20 = PASSWORD ADMINISTRATION 27
FIGURE 21 - ROUTING AND FORWARDING 28
FIGURE 22 - ADVERTISING 29
FIGURE 23 - GRE TUNNELING CONFIGURATION 30
FIGURE 24 - A GRE TUNNEL 31
FIGURE 25 - SERIAL COMMUNICATIONS MENU 32
FIGURE 26 - TCP PAD CONFIGURATION 33
FIGURE 27 - UDP PAD CONFIGURATION 38
FIGURE 28 - PPP CONFIGURATION 39
FIGURE 29 - ADMIN SCREEN CONTROL 40
FIGURE 30 - SPRINT ACTIVATION 41

FIGURE 31 - VERIZON WIRELESS ACTIVATION 42
FIGURE 32 - ACTIVATION CONTROL 42
FIGURE 33 - ACTIVATION LOG 43
FIGURE 34 - MANUAL ACTIVATION 44
FIGURE 35 - SPRINT PRL UPDATE 45
FIGURE 36 - USER DEFINED APPLICATIONS 46
FIGURE 37 - SIM MANAGEMENT 47
FIGURE 38 - AT COMMAND INTERFACE 48

Preface

Welcome to the Ctek Z Series Cellular Router User's Guide. This manual covers the Z4200 EVDO and the Z4400 UMTS/HSPA router. The User's Guide will explain the basic operation of the router and take you through the necessary settings to get your wireless application online. Additional information and applicable technical notices can be found at www.ctekproducts.com.
Note that all administrative functions and screens on the two models are identical with the exception of the Wireless Status and Wireless Interface screens, and the Z4200's Activation screen which is replaced on the Z4400 by a SIM Tools menu item.

1 Introduction

Wireless routers provide application and network designers with a bridge between the world of IT infrastructure and the evolving wireless M2M networks. With the Z Series the wireless transport is fully integrated into the product's routing fabric meaning that you can approach the setup and operation of this product much as with any other IP addressable device. Wireless considerations are reduced to the absolute minimum necessary to register and make connections on a network.
A number of optional controllers are available for use with the models covered in this manual including a micro amp standby power controller, an analog/digital I/O controller, and a relay power controller. The operation of these devices is covered in their specific user manual and in applicable TechNotes.

1.1 Theory Of Operation

The Z Series router is a complete IP router that routes traffic over LAN Ethernet (10/100baseT) connections. The wireless features of the router simply extend the IP routing capabilities to include routing and network address translation (NAT) over cellular wireless networks. As with most routers Ctek's Z Series can be viewed as having a Local Area Network (LAN) side and a Wide Area Network (WAN) side. Traffic originating at the router's Ethernet or Serial port is considered LAN traffic. The Wide Area Network connection is over the wireless network's 1XRTT transport.

1.2 Features

This manual covers Ctek Z Series and contains the following feature and functions.

1) Ethernet
    a. Static Addressing
    b. Dynamic (DHCP) Server
    c. Configurable DNS address
    d. Configurable Gateway, Sub net mask, and Broadcast address
    e. Port Forwarding
    f. Service management

2) Wireless Interface
    a. Enable/Disable WAN Interface
    b. Enable/Disable inbound IP requests
    c. DDNS Interoperability with Ctek's enhanced UDP interface
    d. DDNS Interoperability with BIND or MS Server
    e. Administration web server port address selection
    f. Enhanced network activation (Z4200)
    g. Home Network Selection

3) RS232 (DB9 serial port)
    a. Configurable Bit Rate
    b. Configurable for Start/Stop Bits, Flow Control, and Parity
    c. Local and remote Telnet Access
    d. TCP/UDP Packet Assembly and Disassembly (PAD) function.
    e. PPP Interface
4) RS485 Auxiliary Serial Port
    a. Configurable Bit Rate
    b. Configurable for Start/Stop Bits, Flow Control, and Parity
    c. TCP/UDP Packet Assembly and Disassembly (PAD) function.
5) USB Host Connection
6) Relay Contact Closure (detection and operation)
    a. NO/NC detection
    b. SMS or email cry out alarm
7) Relay Driver Output (Maximum sink current 200ma @24V)
    a. SMS Activation
    b. Web Activation
8) General Administration
    a. Modify User and Password
9) Status – Ethernet Status
    a. Currently Assigned IP Address
    b. Current MAC Address
10) Wireless Status – CDMA or HSPA/UMTS Status
    a. ESN or IMSI
    b. Network Assigned IP Address
    c. Telephone Number (MIN) or MSISDN
    d. Current Network Status Active/Inactive
    e. Signal Level (RSSI)

2 Connectors, Lights, Switches, and Jumpers

2.1 Switches

Referring to Figure 1, there are two switches on the front of the Z Series router. S1 (Reset) causes a hard reset of unit. S2 (DFLT) is used to completely restore the firmware settings that were included when the product was shipped from the factory. To restore factory defaults, the unit must be running. You should wait a full two (2) minutes after booting or powering on the unit before restoring factory defaults. After waiting two minutes press the Restore Defaults (inner) switch and hold it down for 10 seconds. After 10 seconds, you will see both the green and yellow lights go off. At that time you may either press the reset (outer) switch or cycle power on the unit.



Figure 1 - Lights and Switches

2.2 Lights

The Z Series router has indicators as shown in Figure 1.

LAN – The LAN light indicates that the Ethernet port is connected to an active Ethernet device.

The network status indicators LINK and SVC are interpreted as follows:

SVC – Multi-color (yellow/green). Indicates:

a) Power
b) RSSI

Display	Definition
Off	No Power
Yellow Blinking	Power On – No Signal (RSSI)
Yellow Solid	Power On – RSSI < -88
Green Solid	Power On – RSSI >= -88

Link - Multi-color (red/green). Indicates:

a) Status of IP connection
b) Type of transport (EV-DO or 1xRTT)

Display	Definition
Off	No Connection (IP address)
Green	Connection established on 1xRTT or GPRS
Red	Connection established on EV-DO or HSPA

2.3 Connectors (see figures 3 and 4 below)

RS232 Connector – This connector is a standard RS232 DCE interface. A straight-through RS232 cable should be used. The RS232 connector pin out diagram is shown below.


3 – Transmit Data (TXD) Input
4 – Data Terminal Ready (DTR) Input
2 – Receive Data (RXD) Output
5 – Ground
1 - Data Carrier Detect (DCD) Output
DB9 Female
(DCE)
5
1
9
6
9 – Ring Indicator (RI) Output
6 - Data Set Ready (DSR) Output
8 – Clear To Send(CTS) Output
7 – Request To Send (RTS) Input

Figure 2 - DB9 Connector

Ethernet Connector

The Ethernet connector on the Z Series is a standard RJ45 connector with auto polarity sensing and can be used with either a standard Ethernet cable or a reverse (cross over) Ethernet cable.

Terminal Block

Connector J1 supports four separate functions, power, relay contact closure detection, relay driver output, and auxiliary RS-485 serial port serial data. Contact closure pins 2 and 4 are shared with the auxiliary serial port. To option remove the circuit board and locate 3-pin headers JP1 & JP2 behind the green connector. Facing the end of the board containing the green connector JP1 and JP2 should have jumpers center to right to use the discrete I/O (Din, Dout), and JP1 and JP2 should have jumpers center to left to use the auxiliary RS-485 serial port. Auxiliary serial port parameters (baud, parity, etc.) are set using the RS232/485 configuration screen. From the factory the unit ships with the auxiliary RS-485 serial port enabled and configured as a master device.

.

The J1 pin out configuration is as follows:

Terminal Block Pin	JP1 & JP2 (internal) Center to Right	JP1 & JP2 (internal) Center to Left
Pin 1	Din Src – Discrete Input Source	
Pin 2	Din – Discrete Input (See Appendix A)	TR- of RS-485 auxiliary serial port[1]
Pin 3	Dout Gnd – Discrete Output Ground	Ground of RS-485 auxiliary serial port[2]
Pin 4	Dout - Discrete Output[3]	TR+ of RS-485 auxiliary serial port[1]
Pin 5	Power supply Ground	Power supply Ground
Pin 6	Power supply +12VDC	Power supply +12VDC
Notes Note 1 Note 2 Note 3	Connect a 120 ohm resistor across pins 2 --> 4 for multi-drop configurations Available as a third wire ground for use in noisy environments Discrete output is rated at 200ma @ 24 volts maximum sink current	



Figure 3 – Z4200S model connectors



Figure 4 – Z4200U model connectors

3 Start Up

Warning – You must connect antenna(s) to the SMA style antenna connectors on the router before turning it on. Failure to do this could result in erratic start up behavior and could possibly damage the unit.

Note – Z Series routers ship from the factory with DHCP server enabled. The Default Gateway address for the unit is 192.168.1.10. The address of the web based administration is also 192.168.1.10. After you have activated your unit on the wireless network it WILL NOT have a DNS address, meaning that public Internet web access will not work. To load DNS values go to the Ethernet Interface screen, select "Acquire From Wireless Network" and press the update button. At this point the Primary and Secondary DNS addresses in the Ethernet Interface screen will be populated with the DNS addresses provided by your wireless network. As a last step restart both the router and the connected PC.

3.1 Power

Before starting connect the supplied 12VDC power adapter to the power connector described in Section 2. The adapter supplied with your router is suitable for use with 120VAC 60-hertz wall power. If you need a different power solutions contact Ctek.

3.2 Connecting the Antenna

Antennas should be attached to the SMA style antenna connectors described in section 3. The antenna must be connected before powering the unit on. ON the Z4200 the antenna connector to the right of the LAN LED is the primary (transmit/receive) antenna and the connector to the left of the reset button is the secondary or diversity antenna.

3.3 Connecting to the Ethernet Port – Administrative Connection

For a direct Ethernet connection between a PC connect to the Ethernet port using a standard or reverse Ethernet cable. For initial configuration and administration with a PC or workstation Ctek recommends that the PC be set to obtain an IP address and obtain a DNS address automatically. For Windows PCs make the following settings under the networking control panel


General
Authentication
Advanced
Connect using:
Realtek RTL8139 Family PCI Fast Ethernet NIC
Configure...
This connection uses the following items:
Client for Microsoft Networks
File and Printer Sharing for Microsoft Networks
QoS Packet Scheduler
Internet Protocol (TCP/IP)
Install...
Uninstall
Properties
Description
Transmission Control Protocol/Internet Protocol. The default wide area network protocol that provides communication across diverse interconnected networks.
Show icon in notification area when connected
General
Alternate Configuration
You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the appropriate IP settings.
Obtain an IP address automatically
Use the following IP address:
IP address:
Subnet mask:
Default gateway:
Obtain DNS server address automatically
Use the following DNS server addresses:
Preferred DNS server:
Alternate DNS server:
Advanced...
OK
Cancel

Figure 5 - Windows configuration

4 Administration, Configuration and Status

About Addressing – Devices connecting to cellular networks are assigned an IP address by the serving network. Address assignment may either be static or the unit will be dynamically assigned an IP address, depending on arrangements that you have made with your wireless network operator. Dynamically assigned IP address remain in effect for a period of time assigned by the network operator, usually at most a small number of hours.
Ctek's Z Series includes features that manage the temporal nature of dynamically assigned wireless IP addresses. Using the Wireless Configuration screen you can configure your router to use a Dynamic DNS (DDNS) service. Ctek operates a DDNS test bed that allows our customers to observe the performance and reliability of DDNS with their applications. For large-scale commercial applications Ctek recommends that users configure their own DDNS, managed and maintained with the customers ongoing IT operations. The Z Series may also be configured to operate with a standard DNS having Dynamic DNS capabilities. Examples of this type of service would be Berkeley Internet Name Daemon (BIND) and Microsoft Server 2000 and up. For detailed information see Ctek's TechNote S001.
Even if you elect to use a static IP address a DDNS service will add value in two ways. First, when the networks static addressing assignment fails there is a mandatory waiting period before the endpoint is allowed to reinitiate the request for a static address registration. During this period of time the network will dynamically assign addresses to the end point. A DDNS service will make the end point network addressable (by name) during this period of time. Secondly, a name service allows your end point to be known by a name that is independent of network addressing. Addressing a unit by name may be easier for end users to remember and will, over a long period of time, reduce maintenance problems.

4.1 Getting Started

Once the PC has been set up properly and physically connected to the router you are ready to begin configuring the router for your application. To access the Administration menu use any web browser pointed at http:// 192.168.1.10. A login screen appears as shown below. The default User ID is "ctek" (without the quotes) and the default Password is also "ctek". Be sure to change the user ID and password and record your new selections.



Figure 6 - Login Screen

When you have completed the login process you will be presented with the top-level administration menu. Both the Z4200 and Z4400 top level menus are shown below.

Figure 7 - Z4200 Top Menu

Figure 8 - Z4400 Top Menu

Note that the administration menu is divided into four sections. The Interfaces section deals with physical connectivity, managing the connection and subtended devices. Status screens are provided for the wireless and Ethernet interfaces. Services are applications that are within the router core to modify the behavior of a specific interface or to change system wide parameters within the router core. Under the Options category users can find any optional or custom applications and tools provided to maintain the router.

Important Note – The Restart button **must always** be used to apply any changes made on specific Interface or Service screens.

4.2 Interfaces

4.2.1 Configuring The Wireless Interface

The configuration screen for the Model Z4200 (EVDO and 1xRTT) wireless interface is shown below in Figure 8 and described in the text following. Figure 10 and its associated text describes the wireless interface provided with the Model Z4400 for use on HSPA, UMTS, GPRS, and EDGE networks.



Figure 9 - Z4200 (CDMA) Wireless Interface

Network Select – **Note: This setting should only be changed after consulting with Ctek Support.** This pull down menu allows the user to control the home network setting of the CDMA connection, effectively limiting the scope of the Preferred Roaming List (PRL) assigned by your wireless network operator. The possible settings are shown below. The EV-DO choices are only available on the Z4200.


Wireless Interface Configuration
Network Select:
0 - Auto
0 - Auto
1 - Home only
2 - 1xRTT only
3 - 1xRTT home only
4 - 1xRTT PCS only
5 - 1xRTT PCS home only
6 - 1xRTT cellular only
7 - 1xRTT cellular home only
8 - EvDO only
9 - EvDO home only
Enable

Figure 10 - Z4200 Network Select

User Name and Password – Required for activation on some networks. See TechNotes for specific usage.

Wireless Connection – Used to enable/disable the wireless WAN connection.

Disabled – Turn off WAN connection
Enabled – Turn off WAN connection

Use Network's Dynamic IP Address – For most networks this will be the correct selection.

Use The Following Static IP Address – If your selected network is capable of provisioning a static IP address to your application check this box and enter the assigned IP address. See TechNotes for network specific set up.

Enable LCP echo packets – Used on some International networks. For all US networks LCP echo packets should be turned off, meaning this box should be unchecked. If you have questions check with Ctek support.

Select DNS Type – Used to select the appropriate protocol for your Dynamic DNS.

1) **None** – DDNS will not be used.
2) **EW/SMS** – Use Ctek Enhanced Wireless DDNS with SMS updates.
3) **EW/UDP -** Use Ctek Enhanced Wireless DDNS with UDP updates over the EV-DO/1XRTT Air Interface
4) **Standard UDP** – Use a standard BIND, MS2000, or MS2003 DDNS server

Device Name – Establishes the name by which this particular router will be known at the Name Server. This entry must be a fully qualified device name and domain and is limited to 40 characters in total. It is limited to one level of name space definition meaning that all characters to the right of the first "dot" will be assumed to be a component of the resolving server. An example would be *ctek01.thingme.net* where *ctek01* is the name of an individual router and *thingme.net* is the name of the resolving server.

Primary and Secondary Name Server – Enter the IP address of the designated Name Server. Name resolution is not performed on this entry meaning that a numeric IP address of the resolving server is required.

Provide Network Name Server Facilities – Selecting Yes causes this router to provide Name Server services to client Ctek routers configured to use it. If this option is selected additional set up in the Name Services screen will be required.



Figure 11 - Z4400 (HSPA) Wireless Interface

Network Select – Available settings are Automatic, Prefer A Network, or Demand a Network.

Automatic – Allow radio to select network based on SIM and signal quality
Prefer a Network – Similar to Automatic with a bias towards the network ID specified in the Network ID field
Demand a Network – Make every effort to use the network specified in the Network ID field

User Name and Password – Normally blank. Required for activation on some networks. See TechNotes for specific usage.

Wireless Connection – Used to enable/disable the wireless WAN connection.

Disabled – Turn off WAN connection
Enabled – Turn off WAN connection

Inactivity Timer – Used to specify a duration of no outbound or incoming traffic after which the WWAN connection will be re-established.

APN – Provided by the network operator. Determines what IP addresses are assigned to the mobile station, what security methods are used, and how the GSM data network connects to the customer's network.

PDP Address – Provided by the network operator. Specifies the address of a particular device's Packet Data Protocol context area in the network.

Authentication – Available settings are None, PAP, CHAP, BOTH. Usually set to none but may be required on some networks.

Enable LCP echo packets – Used on some International networks. For all US networks LCP echo packets should be turned off, meaning this box should be unchecked. If you have questions check with Ctek support.

SMSC Address – Short Message Service Center Address. A number prefixed with a plus (+) sign that specifies the service center that will handle SMS traffic. Provided by the network operator.

Email Gateway – A number (address) specifying a gateway that will transform email to SMS and SMS to email. Provided by the network operator. Note that emails targeted at SMS delivery have network dependent formats.

Select DNS Type – Used to select the appropriate protocol for your Dynamic DNS.

1) **None** – DDNS will not be used.
2) **EW/SMS** – Use Ctek Enhanced Wireless DDNS with SMS updates. Not currently supported.
3) **EW/UDP -** Use Ctek Enhanced Wireless DDNS with UDP updates over the GPRS/EDGE Air Interface
4) **Standard UDP** – Use a standard BIND, MS2000, or MS2003 DDNS server

Device Name – Establishes the name by which this particular router will be known at the Name Server. This entry must be a fully qualified device name and domain and is limited to 40 characters in total. It is limited to one level of name space definition meaning that all characters to the right of the first "dot" will be assumed to be a component of the resolving server. An example would be *ctek01.thingme.net* where *ctek01* is the name of an individual router and *thingme.net* is the name of the resolving server.

Primary and Secondary Name Server – Enter the IP address of the designated Name Server. Name resolution is not performed on this entry meaning that a numeric IP address of the resolving server is required.

Provide Network Name Server Facilities – Selecting Yes causes this router to provide Name Server services to client Ctek routers configured to use it. If this option is selected additional set up in the Name Services screen will be required.

4.2.2 Configuring The Ethernet Interace

The Ethernet configuration determines how devices connected to the LAN side of router will be addressed, and what the actual address of this router will be on the LAN.



Figure 12 - Ethernet Configuration

Media Type – Determines the type of Ethernet connection. Auto allows router to determine what the connection is. This setting is appropriate for most cases. Other settings are to select either 10Mb (10baseT), 100Mb (100baseT), Full Duplex (FD), or Half Duplex (HD). Again, in almost all cases Auto will correctly determine the proper setting.

DHCP Configuration – These settings determine the network topology of the LAN side of router's network.

Disabled – You must manually configure the IP address and other addressing parameters described in the next section . It is recommended that the router be assigned a private static address of 192.168.1.10.

Enable Server - This router must be assigned a private static IP address, as defined in the next section. It is recommended that an address of 192.168.1.10 be used. The DHCP server will issue dynamic IP addresses to other devices connected to the LAN side. IP addresses will be assigned for up to 50 devices. Address assignment is sequential in the range of 192.168.1.100 – 192.168.1.150.

Enable Client – Some other device on the LAN side of the network is acting as a DHCP server. The router will be assigned a dynamic IP address by the DHCP server.

DNS Address Source – In most cases this parameter should be set to Acquire From Wireless Network. In this case, when you click on the Update button, the router will verify that it has been connected to the wireless network and that the

wireless network has provided DNS addresses. If DNS addresses have been provided, they will be displayed in the Primary and Secondary Address boxes. If addresses have not been provided, you will receive an error indication. At that point, you should allow the router to establish a connection with the wireless network so that it can acquire the DNS addresses. You should then go back into the Ethernet Configuration screen and click on submit again. At this point, the DNS addresses should appear.

If you application requires a specific DNS setting check the User Defined box and manually fill in the DNS IP Address fields below.

DNS IP Address (Primary and Secondary) – The address of the Domain Name Server that your network uses. This should not be confused with the Name Server entries on the Wireless Interface screen. The DNS referenced by these addresses will resolve outbound queries.

IP Address – The IP address assigned to the LAN segment of this router.

NetMask – This parameter is also known as Subnet Mask. Network Mask determines which portion of an IP address is the network portion and which portion belongs to the host. As an example a setting of 255.255.255.0 would indicate that the first three groups of this address (255.255.255) identify the network and that the last group (000 – 254) identify a particular host.

Default Gateway – The Default Gateway is the address of a device that the router will use to reach remote networks or servers through its wireless WAN. In a normal situation where the Z4200/Z4400 is acting as a edge router and is expected to pass incoming Ethernet traffic through to the wireless network, this field should be left blank.

Broadcast Address

If applications on the router need to do a broadcast operation, this is the address that will be used on the Ethernet segment to fulfill the broadcast request.

4.2.1 The RS232/RS485 Interface

This screen sets basic parameters for the RS232 port and the auxiliary serial port. These settings should be made to correspond to those on the far end of the serial connection or serial over IP emulation. The RS232 and RS485 serial ports are available for all applications and can be connected to the TCP or UDB PAD feature. In addition the RS232 port can be configured to establish a Point-To-Point Protocol (PPP) connection over a serial link.


RS-232/485 Configuration
RS-232 (DB-9) Configuration
Bit Rate: 300 1200 2400 4800 9600
19200 38400 57600 115200
Character Length: 7 Bit 8 Bit
Parity: None Odd Even
Flow Control: None Rts/Cts X-on/X-off
Service: None TCP PAD UDP PAD PPP
RS-485 (Aux) Configuration
Bit Rate: 300 1200 2400 4800 9600
19200 38400 57600 115200
Character Length: 7 Bit 8 Bit
Parity: None Odd Even
Service: None TCP PAD UDP PAD
Update
Home

Figure 13 - RS232/485 Configuration

Bit Rate – Selects transmit and receive speed. This setting is available on both the RS232 and RS485 ports.

Character Length – Selects the number of bits representing a character. This setting is available on both the RS232 and RS485 ports.

Parity – Selects the parity bit setting that will match the far end. This setting is available on both the RS232 and RS485 ports.

Flow Control (DB9 Only) – Selects No flow control, Hardware Flow Control (RTS/CTS), or Software Flow Control (XON/XOFF). If RTS/CTS is selected make sure that the cable you are using has those pins connected on both ends. Many pre-manufactured cables either do not terminate these signals or else jumper them into a permanent True state.

Service – determines the mode of operation for the serial ports. Services may be in operation on both serial ports simultaneously.

None - Indicates that a custom application and protocol has been implemented.
TCP PAD & UDP PAD - Selects the appropriate Packet Assembly and Disassembly Service.
PPP - Establishes a PPP connection over the RS232 link

4.2.2 Configuring The Relay Input Interface

This screen configures the connection characteristics of the relay input interface and defines the service associated with this interface. Currently, the relay interface can cause an SMS message to be sent to one or more wireless devices or an e-mail message to be sent to one or more email addresses. The rules and limitations that apply to multiple phone numbers or email addresses are described below.
Appendix A contains schematic information concerning the relay input configuration.

Figure 14 - Relay Input Configuration

Relay Input Trigger – Establishes the conditions under which the Relay Service will be invoked. Unless it is disabled the relay input is sampled at 1000 millisecond (1 second) intervals.
Disabled – Never respond to relay activity
On Closure – Respond when relay contacts go closed
On Opening - Respond when relay contacts go open

Maximum Trigger Rate – This setting determines how often the router will send a “relay event” message. If the relay event is recurring at a rapid rate this setting will prevent an undesirable “flood” of messages. If **Maximum Trigger Rate** is set to **"Always"** the relay input is operating in edge triggered mode. In this mode the router will invoke its assigned service any time that the input transitions to the selected state. So if **ON CLOSURE** is selected an SMS is sent every time that the contacts close. This means that once closure is sensed there can be no other closure event until the contacts are first sensed to be open.

All other modes where Max Trigger Rate has a time value are level sensitive. So if the contacts close an SMS is sent and then the state of the relay input is ignored for a defined period of time. For instance, if **Max Trigger Rate** is set to **5 minutes** an SMS is sent and then the relay input is sampled again in 5 minutes. If the contacts are still closed another SMS is sent. If the relay input is not closed the router reverts to monitoring the relay every second.

SMS Destination Address – This field contains the mobile phone numbers or email addresses to which the SMS message will be sent. Up to five phone numbers or five email addresses may be defined within the following limitations

1. Field length - This field can contain no more than fifty-four (54) characters in total including spaces or commas

2. Phone Numbers - Each phone number must consist of ten (10) numeric characters. Multiple phone numbers may be separated by commas or spaces. Therefore, the following formats are allowed: nnnnnnnnnn,nnnnnnnnnn,nnnnnnnnnn,nnnnnnnnnn,nnnnnnnnnn or nnnnnnnnnn nnnnnnnnnn nnnnnnnnnn nnnnnnnnnn nnnnnnnnnn

3. Email Addresses - email address must be in the form *recipient@Any_Domain.* The recipient portion of the email address must contain a non-numeric character in the first ten characters specified or be less than 10 characters in length. An email address may not exceed forty (40) characters in length. Multiple email addresses may be separated by commas or spaces.

4. Destination phone numbers and email addresses may be interspersed so long as the rules defined above are adhered to.

SMS Alert Message – The text of the message to be sent when the relay interface activates. Limited to 100 characters maximum. Only printable ASCII characters in the range of 32 – 126 decimal (20 – 7E hex) can be included in the message.

4.2.3 Configuring The Relay Output (Driver) Interface

This screen configures the connection characteristics of the relay output interface and defines the service associated with this interface. Currently, the relay output interface can be activated by an SMS message or from a button that can be defined on the Advertising screen described in the Services section.
Appendix A contains schematic information concerning the relay output configuration.

Relay Output Configuration
Set Relay Output State: Off On
Relay Initial Value: Last
Relay Shut Off Timer: Never
Allow SMS Control Of Relay: Yes No
Allow Web Browser Control Of Relay: Yes No
Text For Web Link To Relay:
Update
Home

Figure 15 - Relay Output Configuration

Set Relay Output State – Used to set the current state of the relay driver circuit. The relay driver can be activated and deactivated by changing this setting and pressing update.

Relay Initial Value - This pull down determines the initial state of the relay when the SkyRouter reboots or recovers from a power failure. Choices are On, Off, or Last. Last will return the relay output to the state it was in when the power fail occurred.

Relay Shut Off Timer – The relay driver circuit will revert to its default setting after the number of minutes or seconds specified by this parameter. The two second setting is useful for resetting end point equipment.

Allow SMS Control of Relay – If Yes is checked the relay driver may be activated by sending an SMS with the command "R1" and deactivated by sending an SMS with the command of "R0".

Allow Web Browser Control of Relay – If set to yes a button will appear on the Advertising screen to enable and disable the relay driver circuit.

Text For Web Link To Relay – This text will appear on the advertising screen next to the relay activation button.

4.3 Status

4.3.1 Wireless Status

The Wireless Status interface provides information on the Z Series router's wireless network connection, local operating conditions, and predefined information contained within the radio module. Wireless status information is presented in two levels of detail, summary and detailed. Either level can be refreshed (updated) in real time using the Refresh button at the bottom of the page. The Wireless Status interface is display only. This manual section explains both the Z4200 (CDMA) Wireless Status screen and the Z4400 (HSPA) screen as they are different.

Wireless Status Summary Screen (Z4200)

Figure 16 - Wireless Status (Z4200)

Wireless Status Field Definitions – Summary Display

ESN – An identifier assigned to the CDMA radio for this router. The value is given in decimal (Dec) and Hexidecimal (Hex).

System ID (SID) – Numeric Identifiers assigned to local market areas within a wireless network. Your wireless network operator may request this information if you are having trouble connecting to the network.

Phone Number (MDN) – The circuit side phone number of the CDMA radio in your router. MDN stands for Mobile Directory Number.

Network Status – Either In Service or Out of Service. Indicates the state of the network as seen through your particular router

Signal Level (RSSI) – A measure of the strength of the wireless signal that your router is currently seeing. A larger negative number indicates a marginal network connection. Typically this number will be in the range of -75 - -95dBm although there are many locations where the value will be outside of the typical range.

Service Type – The type of bearer channel this router is operating on. Options are None, 1xRTT and EVDO, or EVDO.

Current IP Address – The Internet Protocol (IP) address assigned to this router by the serving wireless network. If this field is blank a connection does not currently exist.

Band – The range of spectrum that this unit is operating on. Options are PCS or Cellular

Call Status – Indicates the current status of network registration

Idle - - Not registered (disconnected), a unit that is idle will not have a valid IP address.

Connected – Registered and active on the network. A connected unit will have a valid IP address.
Dormant – Registered but inactive. Wireless data connections transition to the dormant status after a brief period of inactivity. The dormant state is a normal condition.

Roam Status – Indicates the network's view of the current geographic location of your router. The possibilities are Not Roaming (Home), Roaming, or Blink Roaming. An indication of Roaming may or may not impact your data transmission costs. Charges are a function of your rate plan, not necessarily linked to the networks notion of roaming.

Temp Alert – Indicates the status of the radio's internal temperature sensing. Options are Temp OK, Over Temp Disconnect, or Over Temp Shut Down. Temp OK indicates that the sensed temperature is less than 85 degrees Centigrade. A Temp Disconnect indicates that the radio is attempting cool down procedures and a Over Temp Shut Down indicates that cool down procedures have failed and the radio has shut down to protect itself.

Wireless Status Details Screen (Z4200)



Figure 17 - Wireless Status Details Z4200

Definitions – Detailed Display

The Wireless Status Details screen is subdivided into four panels, Radio Configuration, Current Status, EV-DO Status and 1xRTT status. All values found on the Summary screen are repeated on the Details screen.

Radio Configuration Panel

Radio Type – Indicates the type of programming originally loaded into the radio module. Distinct radio types do not exist for all networks meaning that a unit operating on a given network may have been repurposed from one of the existing radio types.

PRL Version – The Preferred Roaming List (PRL) currently loaded in the radio module.

Firmware Rev – The revision level of the firmware currently loaded in the radio module.

Hardware Rev – The revision level of the radio module.

MSID – Mobile Station Identification (MSID) a second phone number assigned to the module

Current Status Panel

Current Temp – The temperature currently being sensed by the radio module. Values are in Centigrade.

Activation Status – Indicates whether or not the router has been successfully activated on the serving network.

Network Stability – Indicates whether or not the current network connection is of adequate quality to perform an OTA activation.

1xRTT Status Panel

ECIO – A figure of merit (EC/IO) describing how well the router can hear (forward link) the serving network when all other traffic and noise on the same channel is considered. Lower numbers indicate a better quality connection. A strong (small) RSSI does not necessarily equate to a low EC/IO value.

Channel – The specific CDMA channel that the router is currently using to communicate with the serving network.

EVDO Status Panel – Same as the 1xRTT Status Panel only for the EV-DO bearer.

Wireless Status Screen (Z4400)



Figure 18 - Wireless Status Z4400

Carrier – Often referred to as the Mobile Operator

Network Status – Possible values are "In Service", "No Service", or "Service Denied". Indicates the state of the network as seen through your particular router

Service Type – Indicates the type of network data connection in use. Options are HSPA, UMTS, EGPRS, or GPRS.

WCDMA Band - Indicates the air interface that the radio is operating on

L1 State - Indicates the current state of the radio module

Current Temp – The temperature currently being sensed by the radio module. Values are in Centigrade.

Signal Level (RSSI) – A measure of the strength of the wireless signal that your router is currently seeing. A larger negative number indicates a marginal network connection. Typically this number will be in the range of -75 - -95dBm although there are many locations where the value will be outside of the typical range.

Roam Status – Indicates the network's view of the current geographic location of your router. The possible values are "Not Roaming", or "Roaming". An indication of Roaming may or may not impact your data transmission costs. Charges are a function of your rate plan, not necessarily linked to the networks notion of roaming.

Call Status – Indicates the current status of network registration. Possible values are "Attached", or "Not Attached".

WCDMA Channel - The air interface channel number that the radio is currently operating on

RRC State - The current state of the Radio Resource Control. Indicates up and down channel capabilities.

Current IP Address – The Internet Protocol (IP) address assigned to this router by the serving wireless network. If this field is blank a connection does not currently exist.

Subscriber ID (IMSI) – Identifies the subscriber. IMSI is contained in the SIM.

Equipment ID (IMEI) – Identifies a particular piece of hardware, specifically the radio within the SkyRouter

Radio Type – Displays the Radio Manufacturer

Firmware Rev. – Displays the firmware revision level of the radio.

Phone Number (MSISDN) – The network address of the unit

Short Message Service Center Address. - A number prefixed with a plus (+) sign that specifies the service center that will handle SMS traffic. Provided by the network operator.

Model – The model number of the radio installed.

Hardware Rev. – If available displays the revision level of the radio module

View All Available Networks (button) - When pressed this button will add a third panel to the Wireless Status screen that will display all HSPA/UMTS/GSM networks visible to the radio. It can take 30 or more seconds for this panel to be populated while the radio scans all available spectrum.

4.3.2 Ethernet Status

Indicates the current LAN side IP address that the router is using. MAC Address is a vendor and machine specific identification code.



Figure 19 - Ethernet Status

4.4 Services

4.4.1 Password Administration

Used to change passwords and create users. Be sure to record this information in a secure location.



Figure 20 = Password Administration

4.4.2 Routing and Forwarding Services

The Routing and Forwarding Services screen provides two separate but related functions. First it allows you to forward WAN side IP traffic arriving on a specific IP Port to a specific Port at a LAN side address. In addition to this conventional forwarding feature this screen also allows you to make a Named Service publicly available over the WAN interface. In Figure 18 below WAN side UDP and TCP traffic arriving on Port 88 is redirected to Port 80 of LAN address 192.168.1.102.
The second function performed by this set up screen to allow named services to be made publicly available to WAN side users. Referring again to Figure 18 a service named "*Ctek SkyRouter Demo – San Pedro, CA*" will be advertised or made publicly available. Security for this advertised service is left up to the specific service. If the Advertising feature is used the Administrative Login screen will no longer greet incoming WAN users, instead they will be presented with a Services screen as shown in Figure 19.


Port Forwarding
Block Inbound IP Traffic From Wireless Network: Yes No
Use NAT on all Ethernet traffic to wireless network: Yes No
Forward inbound port 2424 To port 23 Of local address 192.168.2.2 TCP UDP Enable
Advertise this service With the title
Forward inbound port 6785 To port 6785 Of local address 192.168.2.2 TCP UDP Enable
Advertise this service With the title
Forward inbound port 90 To port 80 Of local address 192.168.2.2 TCP UDP Enable
Advertise this service With the title Caltrans Weather Station

Figure 21 - Routing and Forwarding

Block Inbound IP Traffic From Wireless Network – If set to Yes the router's firewall is configured to block any inbound originated (but not response) packets from the wireless network (WAN). This firewall is then selectively modified by the forwarding entries defined through this screen. If this parameter is set to No, the router's firewall is disabled.

Use NAT on all Ethernet traffic to wireless network – For normal operation this parameter should be set to "**Yes**". In some unique situations, you may connect the router to a network where you will be given public address to use on your LAN's Ethernet segment. In such cases, NAT should be turned off. NAT is currently required for operation on all US networks such as Sprint, Verizon or AT&T. Typical environments where NAT would be turned off would be private networks or some types of VPNs and in these cases, the network operator will most likely provide configuration assistance.

Forward Inbound Port – This table allows WAN side packets addressed for specific IP ports to be routed to a specified address on the LAN side.

Of Local Address – Used to specify the LAN side address of the routing operation. With the introduction of the Point-To-Point protocol feature for the RS232 port the routing field edits have been relaxed to allow multiple Class C ranges of IP addresses since the PPP connection will often be connecting into a different LAN segment. The user is cautioned to take extra care to assure that the LAN side address specified is correct for the connection intended. As an example, if the router's base address is set (in the Ethernet Interface screen) to 192.168.1.10 addresses in the range if 192.168.1.11 - 192.168.1.255 are assigned to the Ethernet connection. In this same example the serial/PPP network might reside on a network addresses as 192.168.2.XXX.

TCP – Route TCP/IP traffic

UDP – Route UDP/IP traffic

Enable – Activate this routing setting

Advertise This Service – Display this named service for WAN users. An advertised service is available for access by any user logged in to the SkyRouter. An example of advertising is shown below.

With Title – The advertised name assigned to this service



Figure 22 - Advertising

4.4.3 Tunneling Services



Figure 23 - GRE Tunneling Configuration

Tunnel Select – Places GRE tunnel in operation. Options are None, Tunnel 1, Tunnel 2, Both Tunnel 1 and Tunnel 2

WAN MTU/MRU – Adjusts MTU (Maximum Transmission Units) and MRU (Maximum Receive Units) for 24 bytes of tunnel overhead. Options are Increase for tunnel overhead or Do not increase

TTL Value – The time in seconds that a packet will remain alive in the tunnel. 255 is the recommended setting for normal operation.

Remote Router IP – The network (routable) address of the remote router on the network

Remote Subnet IP – The base address of the subnet of addresses connected through the tunnel

Net Mask (next to Remote Subnet IP) – The mask limiting the range of addresses on the remote subnet

Remote Tunnel IP – The address used to construct the remote end of the GRE tunnel

Local Tunnel IP - The address used to construct the local end of the GRE tunnel

Net Mask (next to Local Tunnel IP) – The mask limiting the range of addresses connecting to the local tunnel



Figure 24 - A GRE Tunnel

4.4.4 Serial Communications Services

Important Note:

This section of the Z4200/Z4400 User Manual describes the administrative controls and basic operation of the Serial Pad feature. Details of dialing and control options are further described in Ctek TechNote TN007 which is available on the Ctek web site at www.ctekproducts.com.

TCP and UDP PAD services and Point-To-Point Protocol (PP) networking services are provided for the DB9 RS232 interface. TCP and UDP PAD services are also provided for the RS-485 serial port available on the green I/O connector. The PAD features map serially transmitted data on to packets transmitted over the routers wireless IP connection and performs a corresponding mapping of packet data on to the appropriate serial connection. The serial connections and assigned PAD functions can operate simultaneously over the wireless network.
Selecting the Serial Communications Services menu item causes a specific PAD selection menu to be displayed as shown below.



Figure 25 - Serial Communications Menu

As noted previously a TCP PAD function and a UDP PAD function is available for both the DB9 serial connection and the RS-485 auxiliary port. The UDP PAD for both connections is identical in all respects and the TCP PAD for both connections differs only in that the DB9 TCP PAD provides for Data Terminal Ready (DTR) call control while the AUX TCP PAD lacks this feature since the physical connection does not support DTR. Images and description of the DB9 PADs is provided below and should also be referenced for an understanding of the RS-485 PAD features.

4.4.4.1 TCP PAD Services


DB9 TCP PAD Configuration
Call Setup Parameters
Answer Mode: AT Cmd Auto
Dial Mode: AT Cmd Auto Demand
AT Cmd Response: On Off
AT Cmd Echo: On Off
AT Escape Sequence: On Off
DTR Call Control: On Off
Local Echo: On Off
Outbound IP Parameters
(Default) Destination 1 IP Address: 72.215.211.114
Destination 2 IP Address:
Destination 3 IP Address:
Destination 4 IP Address:
Destination 1 Port Number: 23
Destination 2 Port Number:
Destination 3 Port Number:
Destination 4 Port Number:
Inbound IP Parameters
Listen Port Number: 5555
Accept calls from all IP addresses
Accept calls from only following IP addresses:
Data Management Parameters
Termination character (dec): 13
Transmit timer (100ms ticks): 10
Block check length: 0
Maximum block size: 80
Session timer (0-60 min): 0
Inactivity timer (0-60 min): 1
Update
Home

Figure 26 - TCP PAD Configuration

Theory of Operation

Call Answering - The TCP PAD offers two standard methods for call answering:

Auto Answer - The PAD automatically responds to a TCP session

AT Command Initiated Answer - The TCP PAD responds to an AT command requesting answer

Call Initiation - The TCP PAD offers three standard methods for call initiation:

AT Command Initiated Dialing - Call setup occurs as the result of an AT dial command

Auto Dial (leased line) Mode - In auto dial (leased line) mode, the PAD provides auto-dial and auto-recovery facilities so that a connection is always available. The PAD may be configured to auto-dial as many as four destinations. If a connection cannot be established with one destination, the PAD will automatically attempt to connect with other configured destinations. Auto dial mode may be configured so that is controlled by DTR to implement DTR dialing.

Demand - In demand dialing mode the TCP PAD will respond to incoming characters by attempting to set up a call to the destinations configured. The PAD may be configured to auto-dial as many as four destinations. If a connection cannot be established with one destination, the PAD will automatically attempt to connect with other configured destinations. The process begins with the first destination specified and continues until a call is successfully established. Subsequent call attempts will begin with the destination that successfully answered on the last outbound call. Demand calls may be terminated (torn down) by the inactivity or session timer.

Selective Call Acceptance - In all modes, the TCP PAD may be configured to selectively accept or reject incoming calls. If this feature is enabled, up to ten incoming IP addresses may be defined as acceptable.

Packet Forming – The TCP PAD accepts characters from the RS-232 interface and assembles them into an outbound TCP message. The PAD provides a number of data management parameters for controlling the formation and transmission of the TCP message.

TCP PAD Hardware Control Signals

The TCP PAD uses the following RS-232 control signals:

Data Set Ready (DSR) Pin 6 – This output signal, sometimes known as Modem Ready, is controlled by the PAD. When the PAD begins operating, DSR will be turned on. Please not that this only indicates that the PAD is operating. It does not indicate that there is a data connection.

Data Carrier Detect (DCD) Pin 1 – This output signal is controlled by the PAD. When a TCP data connection has been established, this signal will be turned on. When a data connection disconnects, this signal will be turned off.

Ring Indicator (RI) Pin 9 – This output signal is controlled by the PAD. It will toggle at a normal ring cadence if there is an incoming call and the PAD is configured for an AT Command answer mode.

Data Terminal Ready (DTR) Pin 4 – This is an input signal. The PAD may be configured to either monitor or ignore this signal. If the signal is being monitored, DTR must be on in order to establish a call. If a call is established and DTR is turned off, the call will be terminated.

TCP PAD PARAMETER DETAIL – Before configuring the TCP PAD, be sure to review the RS-232 configuration screen and ensure that you have selected the proper physical characteristics for the RS-232 hardware interface. Also ensure that you have selected the TCP PAD as the service that will be connected to the RS-232 interface.

Configuration

Call Setup Parameters

Answer Mode

AT Cmd – PAD accepts ATA command for acceptance of an incoming call.

Auto - Pad will automatically accept an incoming call

Dial Mode

AT Cmd – PAD accepts a variety of ATD command formats for establishment of an outbound call.

Auto – PAD automatically attempts to connect to the destinations defined in the Outbound IP Parameters. The PAD will start with destination 1 and will continue to sequence through all defined destinations until a connection is established.

***** NOTE *****: If Auto is selected for Dial Mode, then Answer Mode is effectively disabled since the PAD will be continuously attempting to establish an outbound connection.

Demand - In demand dialing mode the TCP PAD will respond to incoming characters by attempting to set up a call to the destinations configured. The PAD will start with destination 1 and will continue to sequence through all defined destinations (four maximum) until a connection is established. The process begins with the first destination specified and continues until a call is successfully established. Subsequent call attempts will begin with the destination that successfully answered on the last outbound call. Demand calls may be terminated (torn down) by the inactivity or session timer.

AT Command Response

On – Response and error messages generated

Off – No responses or error messages generated

AT Command Echo

On – All characters echoed in command mode

Off - No echo of command characters

AT Escape Sequence – When the PAD is in data mode, it accepts the standard +++ escape sequence to return to data mode. In some applications, this is not desirable.

On – Enables the standard +++ escape sequence

Off – Disables the escape sequence

DTR Call Control * NOTE – Not Available On AUX TCP PAD *****

On – Enables call control based on the state of DTR

Off – PAD ignores state of DTR

Local Echo

On – All characters received in both command and data mode will be echoed.

Off – No echo of local characters will be done. Command characters will still be echoed if AT Command Echo is on.

Outbound IP Parameters – The user may define as many as four destinations that will be used by the PAD

Inbound IP Parameters

Listen port number – Defines the port that the PAD will listen on for incoming connections.

Accept calls from all IP addresses or Accept calls from only the following IP addresses – Allows the user to selectively accept inbound calls based on the source IP address.

Data Management Parameters

Termination Character – The user may define a termination character that will cause any buffered characters to be sent. In conjunction with the Termination Character parameter, the user may define the length of a block check sequence in **Block Check Length** that follows the termination character. This will ensure that LRC or CRC characters following the Termination Character are included in the same outbound message.

Transmit Timer – The user may define a timeout value that will cause any buffered characters to be sent.

Maximum Block Size – The user may define a block size threshold that will cause buffered characters to be sent.

Session Timer – Forces a hang up after a specified period of time without regard to any activity that may be in process. This feature is designed to guard against sessions that are inadvertently left active and could therefore create large network usage fees. When set to zero this timer is disabled.

Inactivity Timer – The user may choose to configure the PAD to terminate a connection if no inbound or outbound data traffic occurs for a defined period of time.

Note: Any Data Management Parameter may be disabled by setting its value to zero.

TCP PAD COMMAND DETAIL – The following is a summary of supported AT commands. Although all commands are shown in upper case, this is not a requirement. Commands may be either upper or lower case. Please note that all unsupported commands will return a standard OK response for compatibility.

Dial Command – The dial command is used to establish a TCP connection. The following is a summary of all supported forms of the dial command:

In the following cases, both the IP address and port number are provided as parameters:
ATD Address Port
ATDAddress Port
ATDT Address Port
ATDTAddress Port
ATDP Address Port
ATDPAddress Port

In the following cases, the port number is retrieved from default Destination 1 of Outbound IP Parameters:
ATD Address
ATDAddress
ATDT Address
ATDTAddress
ATDP Address
ATDPAddress

In the follwoing cases, the IP address is retrieved from default Destination 1 of Outbound IP Parameters:
ATD Port
ATDPort

ATDT Port
ATDTPort
ATDP Port
ATDPPort

In the following case, both the IP address and port number is retrieved from default Destination 1 of Outbound IP Parameters:

ATD

In the following cases, both the IP address and port number is retrieved from the specified Destination of Outbound IP Parameters:

ATDS=1
ATDS=2
ATDS=3
ATDS=4

Hang Up Command – The following command will disconnect a TCP connection:

ATH

Go Back To Online Mode – The following command is used when the user has escaped from data mode to command mode. By issuing this command, the PAD will be returned to data mode
ATO

Escape sequence – When the PAD is in data mode, an escape sequence can be entered that will cause the PAD to go to command mode. The main reason for doing this would be to then issue a Hang Up Command. The escape sequence is the following three characters:
+++

TCP PAD COMMAND RESPONSES – The following is a summary of supported AT command responses. Responses will always be upper case characters.

Response to a valid command
OK

Response to an invalid command
ERROR

Response when connection is established
CONNECT

Response when connection attempt fails or connection is lost
NO CARRIER

When the PAD is in AT answer mode in there is an incoming call, the following message will be displayed at a normal ring cadence:
RING

4.4.4.2 UDP PAD Services


DB9 UDP PAD Configuration
PAD Operational Mode: Client Server
Outbound IP Parameters For Client Mode
Destination IP Address:
Destination Port Number:
Inbound IP Parameters For Server Mode
Listen Port Number: 7078
Accept packets from all IP addresses
Accept packets from only the following IP addresses:
Data Management Parameters
Termination character (dec): 13
Block check length: 0
Transmit timer (100ms ticks): 10
Maximum block size: 80
Update
Home

Figure 27 - UDP Pad Configuration

PAD Operational Mode
Outbound IP Parameters.
Inbound IP Parameters

This setting is used to select whether the UDP PAD will operate in client or server mode. In client mode the PAD will transmit to a server defined by the **Outbound IP Parameters**. In Server mode the PAD will listen for UDP traffic on the Port defined in **Inbound IP Parameters**. The IP address table found in **Inbound IP Parameters** allows the user to specify certain IP addresses that will be listened for. Traffic from all other IP addresses is ignored.

Data Management Parameters

Termination Character

When receiving characters from the serial interface, receipt of this character will cause buffered data to be sent over the TCP connection. If no character is defined buffered data is transmitted based on maximum block size or character timer (defined below).

Block check length

In many cases, there are 1 or 2 bytes of CRC or LRC after a termination character is received and it is usually desirable to have those bytes included in the same packet with the data. This field allows the PAD to buffer those block check bytes before acting on the termination character.

Transmit timer

In the case where the router has buffered transmit data, has not reached the maximum block size, and has not received a termination character, it will transmit the buffered data if it does not receive a character from the RS-232 interface in this period of time. For instance, if this timer is set to 200msc, every time another character is received this timer is reset to 200msc. If the timer expires before the next character is received all buffered data is transmitted.

Maximum Block Size

If router receives this many characters without a timeout or without a termination character the buffered data will be transmitted.

4.4.4.3 Point-To-Point Protocol (PPP) Services (DB9 RS232 Only)

Selecting the RS2323 PPP menu item displays the following screen.



Figure 28 - PPP Configuration

Local IP Address

The IP address assigned to the router end of the PPP connection. This is the address that should be used in the routing screen for devices on the PPP connection.

Remote IP Address

The address of the remote end of the PPP connection. It may refer to a device or a router managing another subnet.

LCP Echo -On/Off

Enables or disables the LCP Echo message over the PPP connection

DNS Address Source – In most cases this parameter should be set to Acquire From Wireless Network. In this case, when you click on the Update button, the router will verify that it has been connected to the wireless network and that the wireless network has provided DNS addresses. If DNS addresses have been provided, they will be displayed in the Primary and Secondary Address boxes. If addresses have not been provided, you will receive an error indication. At that point, you should allow the router to establish a connection with the wireless network so that it can acquire the DNS addresses. You should then go back into the Ethernet Configuration screen and click on submit again. At this point, the DNS addresses should appear.

If you application requires a specific DNS setting check the User Defined box and manually fill in the DNS IP Address fields below.

DNS IP Address (Primary and Secondary) – The address of the Domain Name Server that your network uses. This should not be confused with the Name Server entries on the Wireless Interface screen. The DNS referenced by these addresses will resolve outbound queries.

4.4.5 Admin Screen Services

This service allows the user to control overall local and remote administrative access.



Figure 29 - Admin Screen Control

Port Number For Admin Screen Access – Causes the WAN side web server to listen on a port other than the default of Port 80.

Allow Network Access To Admin Screens – If set to Yes administrative users will be able to connect to router's Admin interface over the 1xRTT or EV-DO/1XRTT network connection. If this selection is set to No only local administration is possible.

4.4.6 Wireless Activation Services (Z4200 CDMA Only)

Note – Before using the Wireless Activation Services Interface for any purpose you must first turn off the router's WAN interface. This is accomplished by setting the Wireless Connection pull down on the Wireless Interface screen to disabled, clicking update, and then doing a restart of the unit.

The Wireless Activation Services interface serves two purposes. First, it provides a mechanism to activate the router on the wireless networks utilizing a form of Over The Air (OTA) activation. Secondly it may be used as a general interface to enter specific commands, known as AT commands, to the router's radio module.

Over The Air Network Activation – If the wireless module in your Z Series router is capable of performing an OTA activation you will be presented with the option to select the appropriate activation method. Currently this capability is limited to the OMA-DM method for Sprint-Nextel or the OTAS method for Verizon Wireless. The Verizon Wireless OTAS also updates the unit's PRL and can be redone whenever a new PRL is required. Sprint OMA-DM is capable of downloading a PRL over the air but the feature is not yet implemented in the network. Because of the differences in PRL strategies the Verizon Activation Services screen is different than the Sprint version.

Figure 30 - Sprint Activation

Figure 31 - Verizon Wireless Activation

Selecting the Over The Air Activation option on either of these screens will cause the actual activation screen (Figure 26) to be displayed.

Figure 32 - Activation Control

Activation Status – Activated or Not Activated

Network Stability – Indicates OK For Activation if during the previous two minute sample period the RSSI is less that (smaller negative number) -99dBm, the SID has not changed, and the unit has access to 1xRTT connectivity. IOTA activations do not currently for when the connection is EV-DO only.

Activate – Causes the unit to contact the network for an over-the-air activation

Status – Refreshes the current screen so that progress can be monitored.

Details – Displays a scrolling screen (Figure 27) with low level messages between the unit and the network. Useful when an activation problem is encountered.

Back – Return to the Activation Services screen.

Detailed information on IOTA or OTAS activations are covered in the TechNote appropriate for your network. The Status and Details buttons can be used to monitor the activations progress.



Figure 33 - Activation Log

Manual Configuration – Manual activations are performed using specific AT commands to program the router's radio module. The Manual Session selection is a general purpose AT command interface that can be used to perform manual activations or to enter and observe other AT commands as required. AT commands (Example ATDT) are entered in the top field on the Manual Activation screen and the resulting radio and/or network status is displayed in the scrolling region below.



Figure 34 - Manual Activation

PRL Updates – (Sprint)

For information on manually updating a PRL on a Sprint router see TechNote TN0015.

To update a PRL on the Verizon Wireless network the activation process should be redone.

***** NOTE ***** Over the air PRL updates on the Sprint network are not currently implemented.



Figure 35 - Sprint PRL Update

4.5 Options

4.5.1 Applications

The Z Series router is capable of installing and managing custom applications. The Applications Services screen is the user interface to manage custom applications. The individual application release documentation will document the individual applications behavior.



Figure 36 - User Defined Applications

4.5.2 Tools

The Tools category offers a limited subset of the TCOPlus feature group. Currently the Over-The-Air Firmware update mechanism is provided.

The entire TCOPlus feature group is available as a purchase option for the Z Series models. For details refer to Ctek Application Programming Note APN001.

4.5.3 SIM Editor (Z4400 HSPA Only)

Many network operators issue SIM cards that do not contain the MSISDN (phone number) assigned to the account. This tools allows you to write the assigned MSISDN on the SIM card for future reference. The MSISDN must also be written to the SIM card for SkyRouters that will be used with Ctek's EWUDP DDNS service.

Figure 37 - SIM Management

4.5.4 AT Commands (Z4400 HSPA Only)

This screen allows the user to write AT style commands directly to the radio module. Equivalent functionality for Z4200 (CDMA) models is available through the Manual Configuration screen available under the Activation menu selection.

Figure 38 - AT Command Interface

5 Specifications

See individual product data sheets

6 Certifications

FCC Part 15

This equipment has been tested and complies with the limits for a Class A computing device according to U.S. Code of Federal Regulations, Title 47, FCC Rules and Regulations Part 15. Operation is subject to the following two conditions:

1) This device may cause harmful interference, and
2) This device must accept any interference received, including interference that may cause undesired operation.

Testing for compliance with Measurement Requirements (CFR 47 Part 22, Paragraph 22.917(b)(2) and Part 24, Paragraph 24.238(a))

WARNING: To reduce any possible hazard due to exposure of the human body to electromagnetic radiation, per FCC OET Bulletin 65, this device is approved for operation using the antenna provided. The antenna installation must provide a separation distance of 20 cm or more between the antenna and all persons to satisfy Maximum Permissible Exposure (MPE) compliance.

7 Appendix A – Discrete I/O Electrical Drawings




ISOLATED APPLICATION
CTEK SKYROUTER
Z4200U/Z4400U
J3
12VDC
Dout
GND
Din
Din Src
GREEN TERMINAL
12VDC
Battery or
DC Powr Supply
+12Vdc
RL1
12 V / 250 mA (Max.)
RELAY SPST
External
Instrument
NON-ISOLATED APPLICATION
CTEK SKYROUTER
Z4200U/Z4400U
J3
12VDC
Dout
GND
Din
Din Src
GREEN TERMINAL
12VDC
Battery or
DC Powr Supply
VCC
External
Instrument
DIGITAL INPUT (ALARM)
DIGITAL OUTPUT (OPEN DRAIN)


NON-ISOLATED APPLICATION
CTEK SKYROUTER
Z4200U/Z4400U
J3
12VDC
Dout
GND
Din
Din Src
GREEN TERMINAL
+3.3 to 24 Vdc
12VDC
Battery or
DC Powr Supply
VCC
External
Instrument
DIGITAL INPUT (ALARM)
DIGITAL OUTPUT